




AASTRA 6753i QUICK REFERENCE

MAKING CALLS

1 HANDSFREE


- + Dial the number to call
- + Press the right arrow key ►
Or
- + Press the handsfree key 
- + Dial the number to call

2 USING HANDSET


- + Pick up the handset
- + Dial the number to call

3 CALL BACK A RECENTLY DIALED PHONE NUMBER

- + Press the redial key 

- + Use the UP ▲ and DOWN ▼ arrow keys to browse the list
- + To dial the displayed number, press the handsfree key 
- + Pick up the handset if handsfree is not desired

4 CALL A PHONE NUMBER FROM CALL HISTORY (INCOMING / MISSED CALLS)

- + Press the **Callers** key (displayed as **Callers** on the printed label)
- + Use the UP ▲ and DOWN ▼ arrow keys to browse the list
- + To dial the displayed number, press the handsfree key 
- + Pick up the handset if handsfree is not desired

TRANSFER CALLS

1 BLIND TRANSFER

- + Press the **Transfer** key (displayed as **Transfer** on the printed label)
- + Dial the extension number of the person you need to transfer the call to
- + Press the **Transfer** key again

2 CONSULTATIVE TRANSFER

- + Press the **Transfer** key (displayed as **Transfer** on the printed label)
- + Dial the extension number of the person you need to transfer the call to
- + Press the right arrow key ►
- + Announce the caller to the person at the extension you are going to transfer the call to
- + Press the **Transfer** key again to complete the transfer



AASTRA 6753i QUICK REFERENCE

CONFERENCE CALLS

- + Press the **Conference** key (displayed as **Conference** on the printed label)
- + The person already on the call (party A) is put on hold
- + Dial the extension number of the person (party B) you want to conference in
- + Press the right arrow key ►
- + Announce to party B that you will conference him/her into the call

- + Press the **Conference** key again to be with both party A and B in the conference

NOTE: You can use the UP ▲ and DOWN ▼ arrow keys to scroll through and see the numbers/ names of the parties in the conference call. Pressing the right arrow key ► will drop the selected party from the call.

ACCESSING VOICEMAIL

Press the **Voicemail** key (displayed as Voicemail on the printed label) or Dial *98 and press the right arrow key ►

ACCESSING VOICEMAIL REMOTELY

CALLING THE MAIN AUTOMATED ATTENDANT PHONE NUMBER

- + Dial the main Automated Attendant phone number of your company
- + You will be requested to enter the extension of the person you are calling
- + Dial 6 + your extension number (ex. If your extension number is 205, then you must dial 6205)
- + Let the call go to your voicemail
- + Once you hear your voicemail greeting, press the star key. You will then be prompted to enter your voicemail password.

CALLING YOUR DIRECT PHONE NUMBER

- + Dial your direct phone number
- + Let the call go to your voicemail
- + Once you hear your voicemail greeting, press the star key. You will then be prompted to enter your voicemail password.

CALLING FROM ANOTHER EXTENSION

- + Dial 6 + your extension number (ex. If your extension number is 205, then you must dial 6205)
- + Let the call go to your voicemail
- + Once you hear your voicemail greeting, press the star key. You will then be prompted to enter your voicemail password.