

QUICK REFERENCE - LINKSYS

*** 9 8** Call voicemail, direct

*** 8 1** Anonymous, one call

*** 6 7** Anonymous, all calls

*** 8 2** Visible, one call

*** 6 8** Visible, all calls

*** 7 1** Enable call waiting, one call

*** 5 6** Enable call waiting, all calls

*** 7 0** Disable call waiting, one call

*** 5 7** Disable call waiting, all calls



babyTEL.NET

QUICK REFERENCE - LINKSYS

*** 6 9** Call return

*** 7 2** **XXX XXX-XXXX:**

Define or change call forwarding (CF) number and activate it on all calls

*** 7 2** 1: Activate CF on all calls

*** 7 2** 2: Activate CF on busy

*** 7 2** 3: Activate CF on no answer

*** 7 2** 4: Activate CF on busy/no A.

*** 7 2** 0: Deactivate CF [all types]

CALL HOLD

Press and release flash hook or the hold button



babyTEL.NET

QUICK REFERENCE - LINKSYS

*** 6 6** Repeat dial on busy
(First hang up, then lift receiver and dial ***66**)

*** 8 6** Cancel repeat dialing

*** 7 8** Enable do-not-disturb

*** 7 9** Disable do-not-disturb

**START
CONFERENCE
CALL**

Flash hook or hold.
Dial third party, wait for answer...

**CONNECT
THIRD
PARTY**

Flash hook or hold.



babyTEL.NET